

# RINIA LED TAPE

## Mini Flex End Cap Installation Instructions

---

Step 1



Cut flex tape down to size on the nearest dotted cutting line.

Step 2



Place the clear end cap onto the flex tape. (The side with the groove should be facing upwards, and at the end.)

Step 3



Pull down to make room for other accessories.

Step 4



Place the metal prongs between the copper and the LED.

Step 5



Place the holding clip in line with the silicone. (The end with the clip facing outwards)

Step 6



Now attach the Join Clip.

Step 7



Press together until clipped in securely.

Step 8



Complete the seal by sliding the clear end cap back until clipped in place.

---